Lab 1: Electrostatics

TRIBOELECTRIC SERIES

The **triboelectric effect** (also known as *triboelectric charging*) is a type of *contact electrification* in which certain materials become electrically charged after they come into contact with another different material *with or without* friction. Rubbing *neutral* glass with *neutral* fur, or a *neutral* comb through the hair, can build up triboelectricity. Most of static electricity is built by triboelectric charging. The polarity and amount of the charges produced differ according to the materials properties (surface roughness, strain, temperature..)

This property was first recorded by Thales of Miletus and the word "electricity" comes from the Greek word for amber, ēlektron. Amber can acquire an **excess** electric charge by contact (or friction) with a material like wool; the same happens to glass rubbed with silk, or hard rubber rubbed with fur. Note that not all the materials can exchange a significant charge when rubbed together, the effect is not very predictable and only broad generalizations can be made.

The following table shows you the triboelectric series for many materials you find around the house. Positive items in the series are at the top, and negative items are at the bottom:

- Human hands (usually too moist, though) Acquires a more positive charge +
- Rabbit Fur
- Glass
- Human hair
- Nylon
- Wool
- Fur
- Lead
- Silk
- Aluminum
- Paper
- Cotton
- Steel
- Wood
- Amber
- Hard rubber
- Nickel, Copper
- Brass, Silver
- Gold, Platinum
- Polyester
- Styrene (Styrofoam)
- Saran Wrap
- Polyurethane
- Polyethylene (like Scotch Tape)
- Polypropylene
- Vinyl (PVC)
- Silicon
- Teflon Acquires a more negative charge -

(The above list is adapted from Nature's Electricity, by Charles K. Adams.)

The **relative position** of two substances in the triboelectric series tells you how they will act when brought into contact. Glass rubbed by silk causes a charge transfer because they are several positions apart in the table (glass"+" and silk"-"). The same applies for wool"+" and amber"-". The farther the separation in the table, the greater the charge transfer effect is.

Reference: http://science.howstuffworks.com/vdg1.htm, retrieved Jan. 20, 2010

State clearly your observations and provide explanations(*using the electrostatics' terminology......* +/- *charge, conduction, induction..*) *for each experiment.*

- a) Rub the plastic straw with a *paper* handkerchief. Then, remove the charged straw and hold it close to a suspended small aluminum foil ball without touching it. You may hold the string by your fingers. What do you see?.....
 - b) Then, to touch the aluminum ball by the straw. Remove the straw from the ball and return it it close to the ball, anew. What do you observe now?
- 2. Rub the straw with a paper handkerchief and hold the straw just above small pieces of paper or cereals. What happens?
- 3. Let flow a thin dribble of water from the tap. Rub the straw with a paper handkerchief and hold the straw close to the dribble of water. What happens and what can you assume for tap water?
- 4. a) Charging and discharging an electroscope. Put the electrometer on the table with the indicating needle vertical. Rub the straw with a paper handkerchief and put the straw in contact with the frame of the electrometer (touch the cap). Repeat his operations several times until the electroscope leaves remain open even the straw is removed. If this doesn't work well, put a piece of aluminum on the cap, approach an electrified straw and make contact with the aluminum foil. Why do the leaves of electroscope open?
 - b) Then, touch the cap of electroscope by your finger. What happens? Explain why?
- 5. Follow the steps below and observe what happen to the leaves of the electrometer **for each step**.
 - a) Place the electrified straw *near the cap* of electroscope but *don't touch it.*....
 - b) With your finger touch the cap.
 - c) Remove your finger
 - d) Move the straw away.....
- 6. a) Rub a balloon against your hair and move it away. The hair sticks up. Why?
 - b) Put the balloon close to a horizontal wooden surface; it will stick on wood. Why?
 - c) Incline the wooden surface and verify if the balloon keeps sticking. Explain what you see.
 - d) Verify if the balloon sticks on the wall. Explain.
 - e) Do you expect a difference for these experiments when air is dry or not?

7. Faraday cage

- a) Describe the basic elements of Faraday cage by using different sources (books, internet).
- b) Explain the function of Faraday cage and give examples of its s use. Assume that an electrometer is placed inside a Faraday cage with removable cap. What should happen if?
- c) You remove cage lid and bring a straw close to electrometer cap. The leaves.....
- d) You close the lid on the cage and bring a charged straw close to cap. The leaves....

